

Audio uplink



Each room or zone can be equipped with an Audio Uplink MRA unit. Speeches, meetings or lectures can be reinforced without the cumbersome installation of P.A.-equipment. Just connect a cabled or a wireless microphone to the MRA input and select the local audio input on the [MRC-controller](#).

Besides it is possible to connect a (balanced) line source to the audio input. This makes it possible to connect a DVD-player, or a laptop when giving a presentation.

Note: The MRA-audio inputs are always mono; even when they are connected to a MPM8.8 stereo system!

The MRA audio input is available in three various colors:

